



# CHAIN REPLACEMENT - MODEL C,D,E


0607



concept2.com



# CHAIN REPLACEMENT - MODEL C,D,E



7.



8.




9.


**Note:**  
 If your rower has a wooden handle, follow steps 10-14.  
 If your rower has a plastic handle, follow steps 15-17.




10.



11.



12. Remove old chain and replace with new chain.






13.



14. Proceed to step 18.

# CHAIN REPLACEMENT - MODEL C,D,E



## CHAIN REPLACEMENT - MODEL C,D,E

